








Power screwdriver
recommended for
faster assembly

phillips
head screws

- | | | |
|------------|---|---------|
| X - 2.50" |  | 10 pcs. |
| Y - 2.00" |  | 60 pcs. |
| AA - 1.25" |  | 6 pcs. |
| Z - .50" |  | 2 pcs. |


-  1 pc.
nesting box
latch
-  1 pc.
eye screw



1

Assemble panel **A** to panel **AA** with 2 screws (X) - 2.5".

Assemble panel **C** to panel **CC** with 2 screws (X) - 2.5".



2

Screw front door panel **A** to panel **B** with 5 screws (Y) - 2".

Screw panel **B** to panel **C** with 5 screws (Y) - 2".


Screw panel **C** to panel **D** with 3 screws (Y) - 2".

Screw panel **D** to panel **A** with 3 screws (Y) - 2".

Screw ladder panel **E** to panel **D** with 2 screws (Z) - 1/2".

Insert tray panel **F** into panel **A**.

Lay 2 roosting posts **G** into notched brackets on panel **B** and **D**.



3

Screw panel **H** to side of panel **C** with 3 screws (X) - 2.5".


Screw panel **I** to side of panel **A** with 3 screws (X) - 2.5".

Screw panel **J** to panel **H** and **I** with 4 screws (Y) - 2".

7

Screw nest box latch to front side of panel (Q) in pre-drilled hole.

Screw eye screw to backside of panel (U) in pre-drilled hole.




4

Screw roof panel **K** to panels **J** and **D** with 4 screws (Y) - 2".

Screw roof panel **L** to panels **J** and **D** with 4 screws (Y) - 2".

Screw roof cap **M** to panels **K** and **L** with 6 screws (Y) - 2" and 2 screws (AA) - 1.25".




5

Screw roof panel **N** to panel **A** and **C** with 4 screws (Y) - 2".

Screw second roof panel **N** to panel **A** and **C** with 4 screws (Y) - 2".

Screw roof cap **O** to roof panels **N** and **N** with 4 screws (Y) - 2" and 4 screws (AA) - 1.25".



6

Screw panel **P** to panel **B** with 2 screws (Y) - 2".


Screw panel **Q** to panel **P** with 2 screws (Y) - 2".

Screw panel **R** to panel **B** and **Q** with 4 screws (Y) - 2".

Insert nesting box bottom panel **S** into nesting box.

Insert nesting box divider panel **T** into nesting box.

Insert nesting box lid panel **U** into panel **B**.



Dowel pins are used for guides. Can be removed with pliers if necessary.

Dowel pins are used for guides. Can be removed with pliers if necessary.