Renaissance 3pc Bistro Set-Table

Item# L-BS692SAL



Congratulations on your purchase of our SUNJOY Renaissance 3pc Bistro Set-Table. Our clear, easy to follow, step-by-step instructions will guide you through the assembly process from start to finish.

WARNING:

- Read and follow all Warnings & Assembly Instructions before attempting to assemble.
- Begin assembly not less than 6 feet from any obstruction such as a fence, garage, house, overhanging branches, laundry line, or electrical wires.
- Some parts may contain sharp edges. Wear protective gloves as necessary.
- Keep children away from assembly area.
- Assemble on level ground.
- Do not over tighten any of the bolts or nuts, but do tighten each bolt and nut until firm.
- Check all nuts and bolts for tightness before and during usage.


IMPORTANT


Please take time to read these instructions thoroughly and follow each step carefully for safe and easy operation. Keep this manual for future reference.

For technical assistance on assembly or replacement parts, call Sunjoy Industries at <u>1-866-578-6569</u> from 8:30AM to 5:30PM EST, or email us at <u>sams@sunjoygroup.com</u>, or visit <u>www.sunjoydirect.com</u> for assistance.


Parts List

No.	Description	Qty
А	Umbrella Hole Cap	1
В	Table Top	1
С	Foot	4
D	Fixed Frame	1
AA	Bolt M6×20	16
BB	Spring Washer M6	16
СС	Flat Washer M6	16
DD	Wrench M6	1
EE	Foot Pad (Pre-assembled on C)	4






Step 1: Use Wrench (DD), Bolt (AA), Spring Washer (BB) and Flat Washer (CC) to connect Fixed Frame (D) and Foot (C). Don't lock tight.



Step 2: Use Wrench (DD), Bolt (AA), Spring Washer (BB) and Flat Washer (CC) to connect Foot (C) and Table Top (B).



Step 3: Put the Table stable and lock all the Bolt tight. Put the Umbrella Hole Cap (A) on the Table Top (B). Assembly Completed!

Care & Maintenance

Before using, clean the Table completely with a soft dry towel. Do not place your Table in wet conditions where there is a risk of rust developing. When not in use, wipe free of any dirt or loose objects, wash with a mild solution of soap and water; rinse thoroughly and dry completely. Do not use strong detergent or abrasive cleaners. When not in use, store in a cool, dry location away from sunlight.

Limited Warranty:

Sunjoy Industries warrants to the original purchaser that this item is free from defects in workmanship and materials for a period of 2 year from the date of purchase, provided the item was factory-sealed at the time of purchase and is maintained with care and used only for personal, residential purposes. Should any manufacturing defect arise within this warranty period, Sunjoy Industries will repair or replace (at our option) any defective merchandise upon proof of purchase; however, transportation and delivery costs, as well as payments to a third party for assembly or disassembly of the item, remain the responsibility of the purchaser. A purchaser of an "open box," previously-returned, or "clearance" item, as well as original purchasers outside of the warranty period, may obtain replacement parts from Sunjoy Industries for products in current production, at nominal cost.

Exclusions:

Items used for commercial, contract, or other non-residential purposes, or items damaged due to acts of nature, vandalism, misuse, or improper assembly are not covered. Corrosion or rusting of hardware is not covered. Proof of purchase (dated register receipt) is required for warranty claims. Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.