


Heirloom Slate Fireplace with Cover

Item# L-OF117PST-A



Congratulations on your purchase of our SUNJOY Heirloom Slate Fireplace with Cover. Our clear, easy to follow, step-by-step instructions will guide you through the assembly process from start to finish.

WARNING:

- Keep all children and pets away from assembly area. Children and pets should be supervised when they are in the area of the Fireplace construction.
- Keep assembly area at least 6ft/1.8m from any obstruction such as a fence, garage, house, overhanging branches, laundry line or electrical wires.
- Some parts may contain sharp edges. When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to the product. Please read all instructions before assembly and use.
- Check all bolts for tightness before use, and periodically check and tighten bolts as necessary.
- Assemble on level ground.
- For outdoor use only.



IMPORTANT

Please take time to read these instructions thoroughly and follow each step carefully for safe and easy operation. Keep this manual for future reference.

For technical assistance on assembly or replacement parts, call Sunjoy Industries at [1-866-578-6569](tel:1-866-578-6569) from 8:30AM to 5:30PM EST, or email us at sams@sunjoygroup.com, or visit www.sunjoydirect.com for assistance.


Parts List

No.	Description	Qty
A	Chimney Top	1
B	Chimney	1
C	Upper Base	1
D	Side Mesh	2
E	Rear Board	1
F	Post	4
G	Door	1
H	Slice	1
I	Door Holder	1
J	Fire Bowl	1
K	Base	1
L	Poker	1
N	Cover	1
AA	Bolt M6x15	26
BB	Flat Washer M6	26
CC	Nut M6	1
DD	Wrench M6	1




Step 1:

Put Upper Base (C) upside down and attach the four Posts (F) on it as shown above. Then lock them by Bolt (AA), Flat Washer (BB) and Wrench (DD). Do not lock tightly.




Step 2:

Set Rear Board (E), Side Mesh (D) and Door (G) between the four Posts (F). Then fix them by Bolt (AA), Flat Washer (BB) and Wrench (DD). Do not lock tightly. Please follow the direction of the arrow label when installing the Door (G).




Step 3:

Put the assembled part on Base (K), then fix Base (K) with Post (F) by Bolt (AA), Flat Washer (BB) and Wrench (DD). Lock all the bolts tightly.




Step 4:

Attach Door Holder (I) to Door (G) by through Door (G), and Slice (H), then fix it by Nut (CC) as shown above.



Step 5:

Attach Chimney Top (A) with Chimney (B) as shown above. Lock them tightly by Bolt (AA), Flat Washer (BB) and Wrench (DD) from the inside of Chimney (B). Then turn the Chimney Top (A) upward after assembly completed.



Step 6:

Put Chimney (B) on Upper Base (C). Open the door and put Fire Bowl (J) in Base (K). Put Poker (L) and Cover (N) nearby.

Care & Maintenance

Before using, clean the fireplace completely with a soft dry towel. When not in use, wipe free of any dirt or loose objects, wash with a mild solution of soap and water; rinse thoroughly and dry completely. Do not use strong detergent or abrasive cleaners. When not in use, recommend the use of patio furniture covers.

Steel components of garden accessories and furniture are treated with rust inhibiting paint. However, due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched.

To minimize this condition, it is recommended that care be taken when assembling and handling the product, in order to prevent the paint from being scratched.

Like all topical coatings, cleaning should be with a non-abrasive neutral pH cleaner, you may call the toll free number 877-738-7325 to obtain it from V-SEAL Sealers.

Limited Warranty

Sunjoy Industries warrants to the original purchaser that this item is free from defects in workmanship and materials for a period of 1 year from the date of purchase, provided the item was factory-sealed at the time of purchase and is maintained with care and used only for personal, residential purposes. Should any manufacturing defect arise within this warranty period, Sunjoy Industries will repair or replace (at our option) any defective merchandise upon proof of purchase; however, transportation and delivery costs, as well as payments to a third party for assembly or disassembly of the item, remain the responsibility of the purchaser. A purchaser of an "open box," previously-returned, or "clearance" item, as well as original purchasers outside of the warranty period, may obtain replacement parts from Sunjoy Industries for products in current production, at nominal cost.

Exclusions

Items used for commercial, contract, or other non-residential purposes, or items damaged due to acts of nature, vandalism, misuse, or improper assembly are not covered. Corrosion or rusting of hardware is not covered. Proof of purchase (dated register receipt) is required for warranty claims. Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.