

Care Instructions:

Wicker Cleaning/Care:

Remove cushions, bolsters, and throw pillows, and stack on a clean and dry surface. Use a mild soap and water to clean. Apply this solution directly to heavily soiled areas. Wipe the entire furniture surface with a damp rag or sponge. Rinse thoroughly with clean water. Dry thoroughly before installing cushions.

Fabric Cleaning/Care:

See attached Sunbrella® care instructions.

Instructions d'entretien:

Nettoyage/Entretien de l'osier :

Retirez tous les coussins et le traversin et empilez-les sur une surface propre et sèche. Lavez-les avec du savon doux et de l'eau. Appliquez cette solution directement sur les zones très sales. Essuyez toute la surface du meuble avec un chiffon humide ou une éponge. Rincez soigneusement avec de l'eau propre. Séchez-les soigneusement avant de réinstaller les coussins.

Nettoyage/Entretien de la toile :

Consultez les instructions d'entretien de Sunbrella® ci-jointes.

Instrucciones de cuidado:

Limpieza/cuidado del mimbre:

Retire los cojines, el soporte, y los cojincillos decorativos y apílelos sobre una superficie limpia y seca. Use agua y jabón suave para limpiar. Aplique esta solución directamente a las áreas excesivamente sucias. Frote toda la superficie del mueble con un paño o una esponja húmeda. Enjuague bien con agua limpia. Seque minuciosamente antes de instalar los cojines.

Limpieza/cuidado del material textil:

consulte las instrucciones para cuidado de Sunbrella® adjuntas.