


Assembly Instructions & User's Manual for Member's Mark Fremont 4pc Deep Seating Set in Slate/ in Indigo

Item Number: Model Number: BGV01523-4SC/BGV01523-4IC Customer Assistance (spare/replacement parts): 1-800-416-3511 or Email: customerservice@agio-usa.com



THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Need Assistance? Visit us at: samsclub.com/membersmarkhelp

Table of Contents

| Quality Statement3 |
|---------------------------------------|
| Important Safety Information3 |
| Before Assembly3 |
| Package Contents4 |
| Product Information5 |
| Sofa |
| Components6 |
| Hardware6 |
| Tools6 |
| Step1-Step27 |
| Table |
| Components8 |
| Hardware8 |
| Tools8 |
| Step1-Step49-10 |
| Care & Use and Storage Instructions11 |
| Warranty Information11 |

Quality Statement

Questions or Comments? We would love to hear about your Member's Mark experience! Visit us at: samsclub.com/membersmarkhelp

Important Safety Information

- Please read all instructions carefully before assembling this furniture.
- For your safety, assembly by two or more adults is strongly recommended.
- Use only vendor-supplied hardware to assemble this item. Using unauthorized hardware could jeopardize the structural integrity of the item.
- Hardware may loosen overtime. Periodically check that all connections are tight.

Before Assembly


- Remove all parts and hardware from the box. Place all items on a carpeted or scratch-free work surface, as this will avoid damaging parts during assembly.
- The shipping box can provide an ideal work surface if none is available.
- Use the components and hardware lists below to identify, inventory and separate each of the hardware and components included.
- To avoid accidentally discarding small components or hardware, do not dispose of any packaging or contents of the shipping carton until assembly is complete.
- DO NOT USE power tools unless it is explicitly identified in this manual as required for use during assembly. Power tools can damage the fasteners, hardware and/or components.
- Do not fully tighten all fasteners / screws until all parts are in place. Failure to follow these instructions may cause the fasteners / screws to misalign during assembly.

Package Contents


1Set / 1Ctn

Box 1 of 1:


| Component | Description | Quantity |
|-----------|-----------------|----------|
| А | Swivel Glider | 2 |
| В | Sofa | 1 |
| С | Coffee Table | 1 |
| D | Furniture Cover | 4 |




Product information



| Description | Part No. | Dimensions | Weight Capacity | Factory Assembly |
|---------------|----------|-------------------------|--------------------|---------------------|
| Swivel Glider | BGV01523 | 28" W *32.5" D *35.5" H | 250lb per seat | Y |
| A.Foot Cap | FC0768 | N/A | N/A | Y |



| Description | Part No. | Dimensions | Weight Capacity | Factory Assembly |
|--------------|----------|-------------------------|--------------------------------|---------------------|
| Sofa | BGV01506 | 74" W *32.5" D *35.5" H | 250lb per seat, total 750lb | Ν |
| A.Foot Cap-1 | FC0607 | N/A | N/A | Y |
| A.Foot Cap-2 | FC0342 | N/A | N/A | Y |




| Description | Part No. | Dimensions | Weight Capacity | Factory Assembly |
|--------------|----------|------------------------|--------------------|---------------------|
| Coffee Table | AKE08719 | 23.75" W *42" D *20" H | N/A | Ν |
| A.Foot Cap | FC0614 | N/A | N/A | Y |

| _ | | |
|---|--|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

| Description | Part No. |
|--------------------------|----------|
| Swivel Glider's Cover | ZZW04612 |
| Sofa's Cover | ZZW04712 |
| Coffee Table's Cover | ZZW04812 |

Components




Hardware




Tools

| (H3) HEX BOLT DRIVER PART NO:HW0006 Qty: 1 | |
|---|--|
| | |


Step 1 - Step 2 Step 1



Step 2



Components




Hardware




Tools

|) K BOLT DRIVER RT NO:HW0006 : 1 | |
|---|--|
|---|--|




Step 2






Hand tighten only 2-3 turns.



Step 4



Care & Use Instructions

CARE AND MAINTENANCE

FRAMES

Cleaning - Use mild soap and warm water. Do not use abrasive materials, cleansers or bleach products. Rinse with clean water and dry thoroughly.

Maintenance - Periodically clean and dry thoroughly. Be sure to drain any water accumulated inside the frames. To thoroughly drain frames, remove foot caps and tilt the frames, if necessary, to remove all water. This is critical. Water allowed to accumulate inside the frames and then exposed to sub-freezing temperatures can cause damage to the frame tubing. Always clean, drain and dry thoroughly before storing for the winter. For best results, always store or cover your furniture when not in use. We recommend commercially available outdoor furniture covers. Any small nicks or scratches can be covered with a light application of touch-up paint.

** When cleaning or moving large or heavy items, always have two people work together. Never drag furniture.

FABRICS (CUSHIONS/SLINGS)

Cleaning - Wipe minor spills immediately. Clean with mild soap, warm clean water and soft cloth. Do not use abrasive materials, cleansers or bleach products. Although fabric has been treated to resist stains, occasional use of commercially available fabric cleaners may be necessary. Follow manufacturer's instructions.

Maintenance - The best way to maintain the beauty of cushions and slings is to store them in a dry area and out of the elements when not in use or cover with commercially available outdoor furniture covers.

Furniture covers are a great way to protect your set from harsh elements of weather and UV light. However, it is important to ensure furniture and covers are free of moisture and debris before covering. It is also necessary to promptly uncover furniture after rain and during periods of high humidity to prevent moisture build up. Failure to do so can lead to permanent surface and finish damage.

STRAPS

Cleaning - Wash frequently with mild soap, warm water and a soft cloth. Rinse thoroughly with warm, clean water. Do not use abrasive materials, cleansers or bleach products.

Maintenance - Periodic application of commercially available vinyl cleaners and vinyl protectors will enhance the look and prolong the life of straps. If your strap chair has cushions, make sure any vinyl protectors applied are completely dry before placing cushion back on the chair.

Warranty Information

This product component has a 5 year guarantee against defects in material and/or workmanship. If you have any questions regarding the warranty or spare / replacement parts, please call our toll-free number 1-800-416-3511 or email us at customerservice@agio-usa.com

NOTE: Please consider recycling all applicable packaging material.

Distributed by Sam's West Inc. 2101 SE Simple Savings Dr. Bentonville, Arkansas 72716-0745

Made in China

