



Assembly Instructions & User's Manual


For

Member's Mark Santa Monica 4pc Seating Set

Item Number: xxxxxxxx

Model Number: GC-41081-4PC

**Customer Assistance (spare/replacement parts): 1-800-691-2824
or Email: customerservice@coronadocasuals.com**



THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Table of Contents

Quality Statement.....	3
Important Safety Information	3
Before Assembly	3
Care & Use	3
Product Information	4
Coffee Table	
Package Contents.....	4
Components	5
Hardware	5
Tools.....	5
Step 1	6
Step 2.....	7
Step 3	8
Step 4.....	8
Sofa	
Package Contents.....	9
Components	10
Hardware	10
Tools.....	10
Step 1	11
Step 2.....	12
Step 3	13
Furniture Cover.....	14
Warranty Information	15

Quality Statement

Questions or Comments?

We would love to hear about your Member's Mark experience! Visit us at:
samsclub.com/membersmarkhelp



Important Safety Information

- *Please read all instructions carefully before assembling this product.*
- *Where applicable, and for your safety, assembly by an adult is strongly recommended.*
- *Use only vendor-supplied hardware to assemble this item. Using unauthorized hardware could jeopardize the structural integrity of the item.*
- *Hardware may loosen overtime. Periodically check that all connections are tight.*

Before Assembly

- *Remove all parts and hardware from the box. Place all items on a carpeted or scratch-free work surface, as this will avoid damaging parts during assembly.*
- *The shipping box can provide an ideal work surface if none is available.*
- *Use the components and hardware lists below to identify, inventory and separate each of the hardware and components included.*
- *To avoid accidentally discarding small components or hardware, do not dispose of any packaging or contents of the shipping carton until assembly is complete.*
- **DO NOT USE** power tools unless it is explicitly identified in this manual as required for use during assembly. Power tools can damage the fasteners, hardware and/or components.
- *Do not fully tighten all fasteners / screws until all parts are in place. Failure to follow these instructions may cause the fasteners / screws to misalign during assembly.*

Care & Use

- *Use a soft, clean cloth that will not scratch the surface when cleaning.*

Product Information

Product Dimensions:

Swivel glider: 32.25" x 34.5" x 32.5" (81.9cm x 87.6cm x 82.6cm)

Sofa: 80.25" x 34.5" x 32.5" (203.84cm x 87.6cm x 82.6cm)

Coffee table: 48" x 26.25" x 20" (121.9cm x 66.68cm x 50.8cm)

Product Weight Capacity


Swivel glider: Supports up to 300 lbs. (136 kg)

Sofa: Supports up to 300 lbs per seat. (136 kg)

Coffee table: Supports up to 350 lbs. (160 kg)

Coffee Table



Package Contents



Component	Description	Quantity	Component	Description	Quantity
A	Table top	1	E	Allen/Hex Bolt M6x25mm	12
B	Table leg 1	2	F	M6 Washer	12
C	Table leg 2	2	G	Allen Wrench	1
D	Shelf	1			

Need Assistance? Visit us at: samsclub.com/membersmarkhelp


Components

(A) Table top Qty: 1pc	(B) Table leg 1 Qty: 2pcs	(C) Table leg 2 Qty: 2pcs	(D) Shelf Qty: 1pc
			

Hardware



(E) Allen/Hex Bolt M6x25mm Qty: 12pcs	(F) M6 Washer Qty: 12pcs
	


Tools

(G) M6 Allen Wrench Qty: 1pc


Need Assistance? Visit us at: samsclub.com/membersmarkhelp

Step 1

(A) Table top Qty: 1pc 	(B) Table leg 1 Qty: 2pcs 	(E) Allen/Hex Bolt M6x25mm Qty: 4pcs 
(F) M6 Washer Qty: 4pcs 	(G) M6 Allen Wrench Qty: 1pc 	





Carefully place table top (A) upside down a soft, flat and non-abrasive surface. Attach the table leg 1 (B) to table top (A) with bolts(E) and Washer(F) by using M6 Allen Wrench(G).

Do not tighten the bolts until assembling is completed.

Need Assistance? Visit us at: samsclub.com/membersmarkhelp

Step 2

(A) Table top Qty: 1pc 	(B) Table leg 2 Qty: 2pcs 	(E) Allen/Hex Bolt M6x25mm Qty: 4pcs 
(F) M6 Washer Qty: 4pcs 	(G) M6 Allen Wrench Qty: 1pc 	




Attach the table leg 2 (C) to table top (A) with bolts(E) and Washer(F) by using M6 Allen Wrench(G).

Do not tighten the bolts until assembling is completed.

Need Assistance? Visit us at: samsclub.com/membersmarkhelp


Step 3

(D) Shelf Qty: 1pc 	(E) Allen/Hex Bolt M6x25mm Qty: 4pcs 	(F) M6 Washer Qty: 4pcs 	(G) M6 Allen Wrench Qty: 1pc 
---	---	--	---



Attach the Shelf (D) to table leg 1 (B) and table leg 2 (C) with bolts(E) and Washer(F) by using M6 Allen Wrench(G).
Tighten all bolts with Allen wrench (G).

Step 4




Carefully turn the table over.
The coffee table is ready for your enjoyment.
If the sofa is uneven, you can adjust the feet to make it even.

Need Assistance? Visit us at: samsclub.com/membersmarkhelp

Sofa



Package Contents



Component	Description	Quantity	Component	Description	Quantity
A	Sofa frame	1	C	Allen/Hex Head Bolt M6x45mm	7
B	Sofa seat plate	1	D	M6 washer	7
			E	M6 Plastic washer	4

Need Assistance? Visit us at: samsclub.com/membersmarkhelp


Components

(A) Sofa frame Qty: 1pc	(B) Sofa seat plate Qty: 1pc
	

Hardware



(C) Allen/Hex Head Bolt M6x45mm Qty: 7pcs	(D) M6 washer Qty: 7pcs	(E) M6 Plastic washer Qty: 4pcs
		


Tools

(F) M6 Allen Wrench Qty: 1pc


Need Assistance? Visit us at: samsclub.com/membersmarkhelp

Step 1

(A) Sofa frame Qty: 1pc 	(B) Sofa seat plate Qty: 1pc 	(C) Allen/Hex Head Bolt M6x45mm Qty: 4pcs 	(D) M6 washer Qty: 4pcs 
(E) M6 Plastic washer Qty: 4pcs 			




Carefully place sofa frame(A) upside down a soft, flat and non-abrasive surface. Attach the sofa seat plate (B) to sofa frame (A) with bolts(C), M6 Plastic washer(E) and Washer(D) by using Allen Wrench(F).

Do not tighten the bolts until assembling is completed.

Need Assistance? Visit us at: samsclub.com/membersmarkhelp

Step 2


(C) Allen/Hex Head Bolt M6x45mm Qty: 3pcs	(D) M6 washer Qty: 3pcs
	




Attach the sofa seat plate (B) to sofa frame (A) with bolts(C) and Washer(D) by using Allen Wrench(F).

Tighten all bolts with Allen wrench (F).

Step 3

(G) Seat cushion Qty: 3pcs	(H) Back cushion Qty: 3pcs
	



Carefully turn the sofa over.

Place the seat cushions (G) and back cushion (H) on the sofa.


The sofa is ready for your enjoyment.

If the sofa is uneven, you can adjust the feet to make it even.

Need Assistance? Visit us at: [samsclub.com/membersmarkhelp](https://www.samsclub.com/membersmarkhelp)

Furniture Cover

Component	Description	Quantity	Component	Description	Quantity
G	Seat cushion	5	K	Sofa	1
H	Back cushion	5	L	Furniture cover for sofa	1
I	Swivel glider chair	2	M	Coffee table	1
J	Furniture cover for Swivel glider chair	2	N	Furniture cover for coffee table	1



For maximum protection, use Heavy Duty Furniture Cover (J&L&N). Fasten adjustable cord lock to secure the cover from wind and snug fit.

Need Assistance? Visit us at: [samsclub.com/membersmarkhelp](https://www.samsclub.com/membersmarkhelp)

Warranty Information

This product component has a 5 year guarantee against defects in material and/or workmanship. If you have any questions regarding the warranty or spare / replacement parts, please call our toll-free number 1-800-691-2824 or email us at customerservice@coronadocasuals.com

NOTE: Please consider recycling all applicable packaging material.

Distributed by Sam's West Inc.
2101 SE Simple Savings Dr.
Bentonville, Arkansas 72716-0745

Made in China



Need Assistance? Visit us at: samsclub.com/membersmarkhelp