




Member's Mark™

Assembly Instructions & User's Manual for
Livingston Leather Reclining Sofa



Model Number: KM.9879S / KM.9879S-CO / KM.9879S-CH






Customer Assistance (spare/replacement parts): 1-877-334-0900

or Email: ConsumerCare@ColeandRye.com

Before Assembly

Remove all components from the box. To report information regarding damaged or missing parts or if you have any questions, please call 1-877-334-0900. Please read all instructions carefully before assembling this product. THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE. **Please consider recycling all applicable packaging material.**

Components


Component	Description	Quantity	Pic
A	Chair Base	1	
B	Right Back Post	1	
C	Left Back Post	1	
D	Chair Back	3	
E	AC Power Code	1	

Need Assistance? Visit us at: [samsclub.com/membersmarkhelp](https://www.samsclub.com/membersmarkhelp)


Assembly Steps 1- 3

Step 1: Remove 1 Right Back Post (B) and 1 Left Back Post (C) from the bottom of the Chair Base (A).


Step 2: Untie the AC Power Code (E) and remove.




Step 3: Plug the 3 Chair Back (D) into the Chair Base (A) correctly and buckle the 1 Right Back Post (B) and 1 Left Back Post (C) on the the Chair Base (A) one by one.




Need Assistance? Visit us at: [samsclub.com/membersmarkhelp](https://www.samsclub.com/membersmarkhelp)



Step 4: Make sure the AC Power Code (E) is wired up correctly so that the devices can charge via USB port.



Need Assistance? Visit us at: samsclub.com/membersmarkhelp



Care & Use Instructions

- Water Based Cleaner “W”: Spot clean cloth using only a water-based cleaning agent such a mild detergent or non-solvent upholstery shampoo product. Apply with a soft cloth in a circular motion. Vacuum when dry.
- It is recommended to not place furniture in direct sunlight and keep furniture 2 ft. / 60 cm from heat sources to avoid fading.

Technical Data

Overall Sofa Dimensions: 82.7” x 38.6” x 41” (210 cm x 98 cm x 104 cm)

Overall Sofa Weight: 200.2 lbs.

Safety and Warranty Information

This product component has below guarantee against defects in material and/or workmanship:

- Frame (internal / external): 5 years
- Fabric / Finish / Seat Suspension / Cushioning: 1 year
- Labor: After 1st year, warranty covers only parts and materials, not labor required for repairs.

If you have any questions regarding the warranty or spare / replacement parts, please call our toll-free number 1-877-334-0900 or email us at ConsumerCare@ColeandRye.com

Distributed by Sam's West Inc.
2101 SE Simple Savings Dr.
Bentonville, Arkansas 72716-0745
Made in China

Questions or Comments?
We would love to hear about your
Member's Mark experience! Visit us at:
samsclub.com/membersmarkhelp



FCC marking:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC instruction:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Need Assistance? Visit us at: samsclub.com/membersmarkhelp