

# Assembly Instructions & User's Manual for Member's Mark Heritage 5pc Dining Set in Indigo

Item Number: 990018737

Model Number: BFW00501-5IC

Customer Assistance (spare/replacement parts): 1-800-416-3511

or Email: customerservice@agio-usa.com



THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

## **Table of Contents**

Quality Statement	3
Important Safety Information	3
Before Assembly	3
Package Contents	4
Product Information	5
Swivel Rocker	
Components	6
Hardware	6
Tools	6
Step1-Step3	7-8
Dining Table	
Components	9
Hardware	9
Tools	9
Step1-Step4	10-11
Care & Use and Storage Instructions	12
Warranty Information	12

#### **Quality Statement**

Questions or Comments?
We would love to hear about your
Member's Mark experience! Visit us at:
samsclub.com/membersmarkhelp

### Important Safety Information

- Please read all instructions carefully before assembling this furniture.
- For your safety, assembly by two or more adults is strongly recommended.
- Use only vendor-supplied hardware to assemble this item. Using unauthorized hardware could jeopardize the structural integrity of the item.
- Hardware may loosen overtime. Periodically check that all connections are tight.

### **Before Assembly**


- Remove all parts and hardware from the box. Place all items on a carpeted or scratch-free work surface, as this will avoid damaging parts during assembly.
- The shipping box can provide an ideal work surface if none is available.
- Use the components and hardware lists below to identify, inventory and separate each of the hardware and components included.
- To avoid accidentally discarding small components or hardware, do not dispose of any packaging or contents of the shipping carton until assembly is complete.
- DO NOT USE power tools unless it is explicitly identified in this manual as required for use during assembly. Power tools can damage the fasteners, hardware and/or components.
- Do not fully tighten all fasteners / screws until all parts are in place. Failure to follow these instructions may cause the fasteners / screws to misalign during assembly.

## **Package Contents**

#### 1Set / 2Ctn


#### Box 1 of 2:

Component	Description	Quantity
А	Swivel Rocker	4
В	Table Leg	4
С	Leg Connector Bracket	1
D	Furniture Cover	1



#### Box 2 of 2:

Component	Description	Quantity
А	Table Top	1



## **Product information**



Description	Part No.	Dimensions	Weight Capacity	Factory Assembly
Swivel Chair	BFW00501	27.25"D*23.5"W*37"H	250lb	N
A.Foot Cap	FC0370	N/A	N/A	Y



Description	Part No.	Dimensions	Weight Capacity	Factory Assembly
Table	ALY13613	45.75"RD*28.75"H	N/A	N
A.Foot Cap	FC0607	N/A	N/A	Y



Description	Part No.
Furniture Cover	PCT2104T

## Components

A. CHAIR FRAME Part No.SR0263 Qty 1	B. LEFT ARM Part No.SR0264 Qty 1	C. RIGHT ARM Part No.SR0265 Qty 1
D. BASE AND ROCKER ASSEMBLY Part No.SR0266 Qty 1		

## **Hardware**


(H1) 1/4" X 30 MM BOLT PART NO:HW0817 Qty: 4	(H2) 5/16" X 35 MM BOLT PART NO:HW0820 Qty: 4	(H3) 1/4" X 45 MM BOLT PART NO:HW0805 Qty: 2
(H4) Ø8.0 X 2.3 MM SPRING WASHER PART NO:HW0003 Qty: 4	(H5) Ø6.5 X 1.0 MM WASHER PART NO:HW0004 Qty: 6	(H6) U" METAL PLATE PART NO:HW0760 Qty: 2
(H7) 5/16" NUT PART NO:HW0015 Qty: 4	(H8) Ø6.5 X 1.6 MM SPRING WASHER PART NO:HW0443 Qty: 4	(H9) ROCKER PLATE FACTORY ASSEMBLY PART NO:G0228 Qty: 2


### **Tools**

(H10)	(H11)	(H12)
HEX WRENCH-1	HEX WRENCH-2	HEX BOLT DRIVER
PART NO:HW0007	PART NO:HW0008	PART NO:HW0006
Qty: 1	Qty: 1	Qty: 1


## Step 1 - Step 3

#### Step 1





#### Step 2



NOTE: Bolts must be FULLY tightened.


#### Step 3

(H2) 5/16" X 35 MM BOLT Qty: 4	(H4) Ø8.0 X 2.3 MM SPF Qty: 4	(H6) U" METAL PLATE Qty: 2	
(H7) 5/16" NUT Qty: 4	(H10) HEX WRENCH-1 Qty: 1	(H11) HEX WRENCH-2 Qty: 1	6 6


#### **CAUTION:**

1.Note the horseshoe shape of the rocker plate. Point the open end of the horseshoe away from you. The arrows on the rocker assembly should be pointing towards you.

2.Failure to place "U" metal plates (H6) under the rocker plates and above the "U" bar exactly as shown in the diagram will cause the bolt heads and nuts to damage the structure of the rocker plates and the "U" bar. Damage due to over tightening of bolts or improper assembly could cause injury and may void your warranty.



## Components



### **Hardware**


(H1)	(H2)	(H3)
1/4" X 35 MM BOLT	Ø6.5 X 1.0 MM WASHER	Ø26 X Ø6.5 X2.0 MM WASHER
PART NO:HW0046	PART NO:HW0004	PART NO:HW0624
Qty: 8	Qty: 8	Qty: 8
(H4) 1/4" NUT PART NO: HW0014 Qty: 8	(H5) UMBRELLA HOLE RING (FACTORY ASSEMBLY) PART NO:G0157 Qty: 1	


#### **Tools**

(H7) HEX WRENCH PART NO:HW0009 Qty: 1
---------------------------------------


## Step 1 - Step 4


#### Step 1






### Step 2






#### Step 3



#### Step 4



#### **Care & Use Instructions**

#### **CARE AND MAINTENANCE**

#### **FRAMES**

Cleaning - Use mild soap and warm water. Do not use abrasive materials, cleaners, or bleach products. Rinse with clean water and dry thoroughly.

Maintenance - Periodically clean and dry thoroughly. Be sure to drain any water accumulated inside the frames. To thoroughly drain frames, remove foot caps and tilt the frames, if necessary, to remove all water. This is critical. Water allowed to accumulate inside the frames and then exposed to sub-freezing temperatures can cause damage to the frame tubing. Always clean, drain, and dry thoroughly before storing for the winter. For best results, always store or cover your furniture when not in use. We recommend commend available outdoor furniture covers. Any small nicks or scratches can be covered with a light application of touch-up paint.

\*\* When cleaning or moving large or heavy items, always have two people work together. Never drag furniture.

FABRICS (CUSHIONS/SLINGS)
Cleaning - Wipe minor spills immediately. Clean with mild soap, warm clean water, and a soft cloth. Do not use abrasive materials, cleaners, or bleach products. Although fabric has been treated to resist stains, occasional use of commercially available fabric cleaners may be necessary. Follow manufacturer's instructions.

Maintenance - The best way to maintain the beauty of cushions and slings is to store them in a dry area and out of the elements when not in use or cover with commercially available outdoor furniture covers.

Furniture covers are a great way to protect your set from harsh elements of weather and UV light. However, it is important to ensure furniture and covers are free of moisture and debris before covering. It is also necessary to promptly uncover furniture after rain and during periods of high humidity to prevent moisture build up. Failure to do so can lead to permanent surface and finish damagé.

#### **STRAPS**

Cleaning - Wash frequently with mild soap, warm water, and a soft cloth. Rinse thoroughly with warm, clean water. Do not use abrasive materials, cleaners, or bleach products.

Maintenance - Periodic application of commercially available vinyl cleaners and vinyl protectors will enhance the look and prolong the life of straps. If your strap chair has cushions, make sure any vinyl protectors applied are completely dry before placing cushion back on the chair.

#### **CERAMIC TILE**

Use clean water and mild detergent or commercially available ceramic tile cleaners as necessary. Do not use abrasive materials or cleansers as they may scratch the surface of the tiles. Dry with soft cloth. Do not use commercially available ceramic tile cleaners on table frame.

#### **UMBRELLA USAGE WARNING!**

If you will be using an umbrella with your table, make sure the plastic umbrella ring is inserted into the hole in the center of the table. Place the umbrella through the opening and into an umbrella stand made of cast iron, wrought iron, steel plate or blow molded plastic filled with 20-50 lbs or 9-22 kgs of sand and water. If your table is 72" or 182 cm or larger, we recommend a weight of at least 50 lbs or 22 kgs or more. NEVER USE AN UMBRELLA WITH A TABLE WITHOUT USING AN UMBRELLA BASE AND RING AS DESCRIBED ABOVE. ALWAYS REMOVE YOUR UMBRELLA FROM THE TABLE WHEN NOT IN USE. NEVER USE AN UMBRELLA DURING STORMS OR WINDY CONDITIONS.

### **Warranty Information**

This product component has a 5 year guarantee against defects in material and/or workmanship. If you have any questions regarding the warranty or spare / replacement parts, please call our tollfree number 1-800-416-3511 or email us at customerservice@agio-usa.com

NOTE: Please consider recycling all applicable packaging material.

### Distributed by Sam's West Inc. 2101 SE Simple Savings Dr. Bentonville, Arkansas 72716-0745

Made in China

