

## **Assembly Instructions & User's Manual**


for

# GREYSON COLLECTION 3-piece chair with accent table set

Item Number: 990286387

Model Number: 2821-8562F-48&58

Customer Assistance (spare/replacement parts): 1-800-318-9669



THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

## **Table of Contents**

Quality Statement	3
Important Safety Information	3
Before Assembly	3
Care & Use	3
Package Contents	4
Product Information	5
Components	5
Hardware	5
Tools	5
Step 1 – Step 6	6-11
Warning	12
Danger	12
Troubleshooting	12
Care & Use Instructions	12
Technical Data	12
Warranty Information	12

#### **Quality Statement**

#### **Questions or Comments?**

We would love to hear about your Member's Mark experience! Visit us at: samsclub.com/membersmarkhelp

### **Important Safety Information**

- Please read all instructions carefully before assembling this product.
- Where applicable, and for your safety, assembly by an adult is strongly recommended.
- Use only vendor-supplied hardware to assemble this item. Using unauthorized hardware could jeopardize the structural integrity of the item.
- Hardware may loosen overtime. Periodically check that all connections are tight.


#### **Before Assembly**

- Remove all parts and hardware from the box. Place all items on a carpeted or scratch-free work surface, as this will avoid damaging parts during assembly.
- The shipping box can provide an ideal work surface if none is available.
- Use the components and hardware lists below to identify, inventory and separate each of the hardware and components included.
- To avoid accidentally discarding small components or hardware, do not dispose of any packaging or contents of the shipping carton until assembly is complete.
- **DO NOT USE** power tools unless it is explicitly identified in this manual as required for use during assembly. Power tools can damage the fasteners, hardware and/or components.
- Do not fully tighten all fasteners / screws until all parts are in place. Failure to follow these instructions may cause the fasteners / screws to misalign during assembly.

#### Care & Use

- Use a soft, clean cloth that will not scratch the surface when cleaning.
- **NOTE:** Do not place furniture in direct sunlight and keep furniture at least 60 cm / 2 ft from heat sources to avoid fading.

# **Package Contents**



Component	Description	Quantity
Α	Chairs	2
В	Legs	8
С	Table top	1
D	Table leg	1
E	Table leg	1

### **Product Information**

2821-8562F-48 Dimensions: 26.5" x 35" x 35.75" (67.4cm x 88.9cm x 90.8cm)

2821-8562F-58 Dimensions: 18.5" x 18.5" x 22" (47cm x 47cm x 55.9cm)

Chair Weight Capacity: Supports up to 300 lbs. (136 kg.)


## **Components**


(A) Chairs Qty: 2	(B) Legs Qty: 8	(C) Table top Qty: 1
(D) Table leg Qty: 1	(E) Table leg Qty: 1	

#### **Hardware**

(F)	(G)	(H)
1/4" x 1½" L bolts with	1/4" x 2" L bolts with	5/16" x 2¾" L bolts with
washers for table	washers for table	washers for chair
Qty: 1	Qty: 4	Qty: 16


#### **Tools**






Remove all parts from the carton and separate them into part number groups as indicated in the parts list. Open the velcro on the bottom of the chair (A), then take out the legs (B) and hardware bag out of the box.

The other chair does the same.




Attach legs (B) to the four corners of the chair (A) using 5/16"x 2%" L bolts with washers for chair (H) by allen key (I) as shown.

The other chair does the same.




Stick the velcro on the bottom of the chair.


The other chair does the same.



Attach table leg (E) to the bottom of the table top (C) using 1/4"  $\times 2$ " L bolts with washers for table (G) by allen key (I) as shown.



Attach table leg (D) to the table top (C) using 1/4" x 2" L bolts with washer (G) and 1/4" x 11%" L bolts with washers (F) to table leg (E), tighten with allen key (I).



Example of completely assembled product.



Please make sure all screws are tightened securely, otherwise it may affect the use of the chair.



Don't drag the chair on the floor.

#### **Troubleshooting**

Problem	Possible Cause	Prevention / Solution
Tilting / Leaning	Surface not level	Put the chair and table on a level surface
Shaking	Screw is not tightened	Check and tighten the screw

#### **Care & Use Instructions**

- 1. Do not stand on the seat cushion.
- 2. For indoor use only.
- 3. Please do not expose to direct sunlight.
- 4. Please do not place this product near sources of excessive heat.
- 5. Please avoid use of sharp objects on or near this product.
- 6. Use Fabric Cleaner on spills and marks, as general household cleaners can damage fibers and discolor fabrics.
- 7. Clean spills / marks immediately, as stains are harder to remove when they are left unattended.
- 8. For persistent stains and overall cleaning, contact a professional upholstery cleaning company.
- 9. The feet or base of this upholstered product is intended for carpeted surfaces only and not recommended for use on tile, hardwood, or laminate floors. Use of this product directly on these surfaces could cause floor surface damage. Please take appropriate precautions by placing this product on a carpeted surface or by using protective pads.

#### **Technical Data**

N/A

### **Warranty Information**

This product component has a 1 year guarantee against defects in material and/or workmanship. If you have any questions regarding the warranty or spare / replacement parts, please call our toll-free number 1-800-318-9669.

NOTE: Please consider recycling all applicable packaging material.

#### Distributed by Sam's West Inc.

2101 SE Simple Savings Dr. Bentonville, Arkansas 72716-0745

Made in Vietnam

